

Headquarters U.S. Air Force

Integrity - Service - Excellence

The BIOPLUME III Natural Attenuation Model




U.S. AIR FORCE

**Charles J. Newell, Ph.D., P.E.
Groundwater Services, Inc.
Jan. 31, 2001**

Team Members and Funding

- **Hanadi S. Rifai, Ph.D., P.E.**
University of Houston
- **Jim Gonzales, Ross Miller**
AFCEE Tech Transfer Division


Funded by AFCEE Tech Transfer Division



Natural Attenuation Models


Fuel Sites

- BIOSCREEN (*analytical, two decay options, source decay term*)
- ➔ BIOPLUME III (*numerical, electron acceptors*)




Solvent Sites

- ➔ BIOCHLOR (*analytical, sequential reductive dechlorination*)
- RT3D (*complex numerical model*)






Types of Fate and Transport Models

- 1-D vs. 2-D vs. 3-D Advection
- 1-D vs. 2-D vs. 3-D Dispersion
- Deterministic vs. Statistical
- Numerical vs. Analytical
- Transient vs. Steady State
- Constant Source vs. Changing Source




(BIOPLUME III Features)

Model Selection Guidelines


Model Type	Capabilities	Data Needs	Complexity
■ Hand Calcs:	Advection Only	Simple	 “Gilligan”
■ Analytical (BIOSCREEN BIOCHLOR):	Uniform flow Simple source Key NA Processes	Moderate	 “Skipper”
■ Numerical Model (BIOPLUMEIII):	Complex flow Complex sources Pumping	High	 The “Professor”

Strengths of Numerical Models such as BIOPLUME III

- Can model **changing flow directions**
- Can simulate complex **changes in source strength** of
- Can handle **pumping wells, streams, springs**, etc.
- Can model **heterogenieties**



Introduction to BIOPLUME III



BIOPLUME III

- **Core Model Developed by Hanadi S. Rifai (Univ. of Houston)**
- **Interface Developed by ZEI/Microengineering**
- **Funded by AFCEE**
- **Peer-Reviewed by Blue-Ribbon Panel**

BIOPLUME III

- **Two-dimensional, finite difference**
- **Runs on PC in Windows environment**
- **Enhancement over BIOPLUME II**
- **Incorporates anaerobic electron acceptors**

BIOPLUME III

- Based on the USGS MOC dated July 1989
- Simulates transport of six components
 - contaminant
 - oxygen
 - nitrate
 - iron
 - sulfate
 - carbon dioxide

BIOPLUME III Applicability

- Primarily used for natural attenuation
- Predicts plume extent & receptor concentrations:
 - How far ?
 - How long?

BIOPLUME III Limitations

- **Does not account for selective or competitive biodegradation**
- **Simplifies the complex biological redox reactions**

BIOPLUME III Conceptual Biodegradation Model

u Sequential Degradation

Oxygen



Nitrate



Iron(III)



Sulfate



Carbon Dioxide

Aerobic and Anaerobic Electron Acceptors

Electron Acceptor	Type of Reaction	Metabolic By-Product	Redox Potential (pH = 7, in volts)	Reaction Preference
Oxygen	Aerobic	CO ₂	+ 820	<i>Most Preferred</i>
Nitrate	Anaerobic	N ₂ , CO ₂	+ 740	β
Ferric Iron (solid)	Anaerobic	Ferrous Iron (dissolved)	- 50	β
Sulfate	Anaerobic	H ₂ S	- 220	β
Carbon Dioxide	Anaerobic	Methane	- 240	<i>Least Preferred</i>

Redox Reactions




Concept: Combine reduction and oxidation reactions

Xylene oxidation reaction:



Kinetic Models for in BIOPLUME III

- **Monod/Michaelis-Menton**
(For any contaminant)(in BIOPLUME III)
- **First Order Decay**
(For any contaminant) (in BIOSCREEN)
- **Electron Acceptor Limited Biodeg. /**
(“Instantaneous Reaction”)
(For BTEX only) (in BIOSCREEN)




Biodegradation Kinetic Models

First-Order Decay Model

$$C = C_o e^{(-kt)}$$

$$t_{1/2} = 0.693 / k$$



Biodegradation Kinetic Models

Instantaneous Reaction Model

$$DC_R = - \frac{O}{F}$$

DC_R = Change in contaminant concentration due to biodegradation

O = Concentration of Oxygen

F = Ratio of oxygen to contaminant consumed


Biodegradation Kinetic Models

Monod Kinetic Model


$$m = \frac{m_{\max} C}{K_C + C}$$

$$DC = M_t \frac{m_{\max} C}{K_C + C} Dt$$

M_t



Graphical User Interface Platform Menu and Toolbox



Modeling Procedures

- **Establish model purpose**
- **Develop conceptual model**
- **Calibration**
- **Validation**
- **Prediction**

Where to Get **BIOPLUME III**

EPA Center for Subsurface Modeling Support (R. S. Kerr Lab)

- **Web:**
<http://www.epa.gov/ada/csmos/models.html>
- **Phone**
(405) 436 8718

